

## Rotorcase Saddles

Pump Model	Description	Qty	Part No.	Item No.
<b>SRU1</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.031	5268-031
	Fasteners	4	5990.043	5990043
<b>SRU2</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.032	5268-032
	Fasteners	4	5990.012	5990012
<b>SRU3</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.033	5268-033
	Fasteners	4	5990.009	5990-009
<b>SRU4</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.034	9630031955
	Fasteners	4	5990.048	5990-048
<b>SRU5</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.035	5268-035
	Fasteners	4	5990.010	5990-010
<b>SRU6</b>	Jacketed Rotorcase	1	Dependent upon connection size, type and seal arrangement, consult factory	
	Saddle	2	5268.036	9630031959
	Fasteners	4	5990.010	5990-010