


# Agitator Type LKRE

2



# Agitator Type LKRE

Pos.	Qty.	Denomination	Motor KW	60-0060	60-0061
			Propellerdiam.	1,5/2,2	1,5/2,2
		RPM	90	110	
			1500/3000	1500/3000	
1	1	Propeller .....	9611-60-2026	9611-60-2026	9611-60-2061
2	1	Pin (Nylon 4 x 20) .....	9611-99-0626	9611-99-0626	9611-99-0629
3	1	Shaft .....	9611-60-2029	9611-60-2029	9611-60-2053
4	1	Screw .....	9611-99-0323	9611-99-0323	9611-99-0323
5Δ	1	O-ring .....	223406-46	223406-46	223406-46
6	1	Stationary seal ring .....	9611-60-2033	9611-60-2033	9611-60-2033
7Δ	1	O-ring (NBR) .....	9611-99-0087	9611-99-0087	9611-99-0087
8Δ	1	Rotating seal ring .....	31439-0038-1	31439-0038-1	31439-0038-1
9Δ	1	Spring .....	31439-0042-1	31439-0042-1	31439-0042-1
10	1	Front plate .....	9611-60-2034	9611-60-2034	9611-60-2056
11Δ	1	O-ring (NBR) .....	9611-99-0068	9611-99-0068	9611-99-0068
12	1	Welding flange .....	9611-60-2042	9611-60-2042	9611-60-2042
13	6	Set screw .....	9611-99-0365	9611-99-0365	9611-99-0365
14	1	Motor console .....	9611-60-2080	9611-60-2080	9611-60-2080
15	1	Wedge ring .....	9611-60-2044	9611-60-2044	9611-60-2044
16	4	Allen screw .....	9611-99-0322	9611-99-0322	9611-99-0322
17	1	Intermediate ring 9611-60-2045 .....	9611-60-2045	9611-60-2045	9611-60-2045
18	1	Nut .....	9611-60-2046	9611-60-2046	9611-60-2046
19	1	Distance ring .....	9611-60-2047	9611-60-2047	9611-60-2047
20	1	Cover .....	9611-60-2048	9611-60-2048	9611-60-2048
21	1	Cover fixing ring .....	9611-60-2050	9611-60-2050	9611-60-2050
22	1	Motor .....	9611-99-0911	9611-99-0911	9611-99-0911
23Δ	1	Steelring .....			9611-60-2063
24Δ	1	Bush .....			9611-60-2064
25	1	Support bearing .....			9611-60-2065
27	1	Cable gland .....	31801-0154-4	31801-0154-4	31801-0154-4
28	1	Direction arrow .....	9611-99-2519	9611-99-2519	9611-99-2519
29	1	Connection .....	9611-60-2041	9611-60-2041	9611-60-2041
30	1	Nut .....	9611-99-0350	9611-99-0350	9611-99-0350
31	1	Seal .....	9611-99-0197	9611-99-0197	9611-99-0197
32	4	Nut .....	9611-99-0309	9611-99-0309	9611-99-0309
33	1	Washer .....	9611-99-0733	9611-99-0733	9611-99-0733
34	1	Nut .....	9611-99-1696	9611-99-1696	9611-99-1696
35	1	Guard for motor console .....	9611-60-3350	9611-60-3350	9611-60-3350
36	1	Screw .....	9611-99-1373	9611-99-1373	9611-99-1373
37	1	O-ring .....	9611-99-0972	9611-99-0972	9611-99-0972
	Δ	<b>Service kit.....</b>	<b>9611-92-5012</b>	<b>9611-92-5013</b>	

Parts marked with Δ are included in the **Service kit**.